

Legendex Snorkel

Mazda BT50 2021+ Stainless Snorkel to Standard Airbox Installation Instructions:

1. Firstly, tape the front drivers guard and the inside of the A-pillar with masking tape (*this is to prevent scratches when making the hole*).
2. Cut the hole out of the template before placing it and taping it on the guard. Then use a marker to mark the hole directly on the guard.
3. Unscrew and remove the plastic guard liner from under the guard.
4. Remove the plastic pipe to the airbox under the bonnet as well as the airbox bottom half.
5. Cut the hole in the guard (*we use a 102mm hole saw and flappy disk*).
6. Use a file to remove any excess steel from around the hole (*inside and out*).
7. Prime the bare steel with paint.
8. Run the provided pinch weld rubber around the hole and trim it accordingly.
9. Insert the snorkel into the hole to a position it fits best then put the snorkel bracket in the A-pillar and close door. Stand back and make sure it fits and lines up perfectly. Adjust slightly if need be.
10. Mount the bracket inside the A -pillar using the nutserts provided. You will need to make 9mm holes for nutserts.
11. Use the 4-3.5" straight silicon join to the 140mm piece of 3.5 stainless, connect the 3.5-3" 90 silicon join to the stainless and insert through the inner guard
12. Install the supplied pieces of stainless and alloy as per photos attached and re-install the airbox
13. Re-install the plastic guard liner under the guard.



LEGEND EX