



LEGENDEX SNORKEL

4" SHORT ENTRY STAINLESS STEEL SNORKEL

Ford Ranger Next-Gen 2022+



PRODUCT CODE: AS-RAN-3B

STEP 1

Firstly, tape the front drivers guard and the inside of the A-pillar with masking tape (this is to prevent scratches when making the hole).

STEP 2

Cut the hole out of the template before placing it and taping it on the guard. Then use a marker to mark the hole directly on the guard.

STEP 3

Unscrew and remove the plastic guard liner from under the guard. You will also need to remove the external flare and washer bottle. The flare is clipped on. You'll have to reach behind and pinch the clips with your fingers to get the flare off.

STEP 4

Remove the plastic pipe to the airbox under the bonnet as well as the airbox

STEP 5

Cut the hole in the guard (we use an air hacksaw)

STEP 6

Use a file to remove any excess steel from around the hole (inside and out)

STEP 7

Prime the bare steel with paint.

STEP 8

Run the provided pinch weld rubber around the hole and trim it accordingly.

STEP 9

Install the washer bottle as per photos provided. You may have to pop the guard grill out to fit this

STEP 10

Insert the snorkel into the hole to a position it fits best then put the snorkel bracket in the A-pillar and close door. Stand back and make sure it fits and lines up perfectly. Adjust slightly if need be.

STEP 11

Mount the bracket inside the A -pillar using the screws provided.

STEP 12

Install the supplied pieces of stainless and alloy as per photos attached and re-install the airbox

STEP 13

Use the 4" straight silicon join to the piece of 4" stainless, connect the 4-3.5" 90 silicon join to the stainless and mount it on the stainless that's been siliconed into the airbox

STEP 14

Re-install the plastic guard liner under the guard and the flare.



