



# LEGENDEX ROCK SLIDERS

PRODUCT CODE: P-RS-Y62-1

**Nissan Patrol Y62 2013 – 2021**



## CHECK YOUR PACK LIST

Once you have unpacked the system from the box make sure you have all parts that are listed on the packing list below.

### COMPONENTS

RS-Y62-1phs SLIDER PASSENGER SIDE x 1

---

RS-Y62-1phs SLIDER DRIVERS SIDE x 1

---

TREAD BOLTS BOLTS x 4

---

TREAD PLATES PLATE x 4

### TOOLS REQUIRED

- 19mm Spanners | Ratchet Spanner Ideal
- Bottle Jack | Trolley Jack Ideal
- Timber Block | Rubber Ideal
- Rubber Mallet
- Floor Mat
- Portable Light

## IMPORTANT BEFORE INSTALLATION

- Before installing your sliders park your vehicle on level ground ensuring it is in gear (or Park) and the handbrake is applied. Never use a jack to support the weight of the vehicle while working on it.
- Wear protective clothing including eye wear listed on the packing list below.

## REMOVING ORIGINAL SIDE STEPS

- **BEFORE YOU START – DOUBLE CHECK** – that you have the correct sliders for the job.
- Check the invoice and the packaging.
- Remove packaging: Check you have all the correct parts and no damage from freight.
- You might need to wash the underbody before starting the job.
- Generously spray the bolts with WD40 (or other spray lube) and leave to penetrate.
- Each 4wd is different so you'll need to identify the correct spanner size

## INSTALLING YOUR NEW ROCK SLIDERS

### STEP 1

Unpack and remove the bolts attached to the mounting points and put these side.

### DRIVER SIDE

### STEP 2

Start with the Driver Side  
Remove the cable cover located at the front, the second image shows what it looks like once the cover is removed.



### STEP 3

Lift the rear of the slider and align the slider with the body and chassis, you will need to drill out the factory hole 13mm, then bolt up the bracket.



# INSTALLING YOUR NEW ROCK SLIDERS

---

PRODUCT CODE: P-RS-Y62-1

## STEP 4

Lift the front of the slider and align the slider with the body and chassis (this is the same area from which the cover was removed) bolt the bracket into place



## STEP 5

Align the Driver side slider with the body and chassis using a jack, the Bracket will go over and cup the chassis. Do the bolt-through finger tight, once all brackets are aligned go through and tighten.



## STEP 6

Now go back and tighten all the bolts on the driver side Rock Slider

## PASSENGER SIDE

---

## STEP 7

Lift the rear of the slider and align the slider with the body and chassis, you will need to drill out the factory hole 13mm, then bolt up the bracket.



## STEP 8

Lift the front of the slider and align the slider with the body and chassis bolt the bracket into place



# INSTALLING YOUR NEW ROCK SLIDERS

---

PRODUCT CODE: P-RS-Y62-1

## STEP 9

Align the passenger side slider with the body and chassis using a jack, the Bracket will go over and cup the chassis. Do the bolt-through finger tight, once all brackets are aligned go through and tighten.



## STEP 10

Now go back and tighten all the bolts on the passenger side Rock Slider

---

## NOTES

---

---

---

---

---

---

---



## THANKS FOR CHOOSING A LEGENDEX PRODUCT

If you're on Facebook or Instagram we would love to show off your vehicle on our page. Simply tag us in a post with photos of your Legendex product using the tags below and we will feature your vehicle. @legendex on Facebook and Instagram