

Toyota Hilux N80 Stainless Snorkel to Standard Airbox Installation Instructions:

1. Firstly, tape the front drivers guard and the inner A-Pillar with masking tape (*this is to prevent scratches when making the hole*).
2. Cut the hole out of the template before placing it and taping it on the guard. Use a marker to mark the hole directly on the guard.
3. Unscrew and remove the plastic guard liner from under the guard.
4. Remove the plastic pipe to the airbox.
5. Cut the hole in the guard (*we use a 102mm hole saw and flappy disk*).
6. Use a file to remove any excess steel from around the hole (*inside and out*).
7. Prime the bare steel with paint.
8. Run the provided pinch weld rubber around the hole and trim it accordingly.
9. Insert the snorkel into the hole to a position it fits best then put the snorkel bracket in the a-pillar and close door. Stand back and make sure it fits and lines up perfectly. Adjust slightly if need be.
10. Mount the bracket inside the A-pillar using the nutserts provided. You will need 9mm holes for the nutserts.
11. The stock airbox will have to be removed and the “fan” looking piece needs to be knocked off it.
12. Slide the 4” – 3.5” 90° silicon join through the guard till its square with where the airbox will sit, then re-install the airbox. The silicon join will need to be trimmed to suit.
13. Use the other 4” – 3.5” 90° silicon join to connect the end of the snorkel and the airbox (*where you removed the plastic pipe*). This silicon join will need to be trimmed to suit as well.
14. Re-install the plastic guard liner under the guard.