

Toyota Landcruiser VDJ 76/79 Series Stainless Snorkel to Standard Airbox

Installation Instructions:

1. Remove the factory snorkel and the airbox setup. (*You will need to keep the factory snorkel fastenings to use on the new snorkel*).
2. Tape the front drivers guard and the A-pillar with masking tape (*this is to prevent scratches when making the hole*).
3. Cut the hole out of the template before placing and taping it on the guard. Use a marker to mark the hole directly on the guard.
4. Cut the hole in the guard.
5. Use a file to remove any excess steel from around the hole (*inside and out*).
6. Prime the bare steel with paint.
7. Run the provided pinch weld rubber around the hole and trim it accordingly.
8. Insert the snorkel into the hole in the guard and bolt both brackets on using the factory fastenings.
9. Use the 4"-3.5" reducer silicon join, to connect the end of the snorkel to the supplied piece of 3.5" stainless tube. You will then need to connect the 3.5" straight silicon join, to the other end of that piece of stainless tube.
10. Mount the factory airbox back into position in the engine bay and connect the 3.5" silicon join, back to the airbox. You may need to trim the silicon join to make the airbox fit.